PARTS LIST

for

Whirlpool CORPORATION

thin twin

WASHER • DRYER LAUNDRY SYSTEM

MODELS

LT5000XSW1 LT5004XSW1
LT5000XSW2 LT5004XSW2

▲W—White, N—Almond, G—Golden Harvest,
F—Toast, M—Platinum

TABLE OF CONTENTS

	Page No.
Washer/Dryer Control Panel Parts	2,3
Dryer Parts	4-8
Washer Parts	9-17
Sales Accessories	18
Miscellaneous Parts	19
Literature and Optional Parts	19

FSP®

FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS

FSP®

Whirlpool CORPORATION
Benton Harbor, Michigan.

© 1988 WHIRLPOOL CORPORATION

7-88 Litho in U.S.A.

Part No. 693126 Rev.A

747-C-10

WASHER/DRYER CONTROL PANEL PARTS

For Models: LT5000XSW1 and LT5004XSW1
LT5000XSW2 and LT5004XSW2



747-C-11

1	3387713	Harness, Console Wiring (Automatic) (Includes Illus. 1A, 1B & 1C)
1A	342529	Plug, Terminal (2-Way) (Connects With Main Dryer Harness)
1B	696073	Receptacle, Connector (Connects With Lower Automatic Harness)
1C	352089	Disconnect Block (Connects With Automatic Timer)
2	3347890	Timer, Control (60 Hz.) (Automatic Washer)
3	63491	Motor, Timer (60 Hz.)
6	694338	Bracket, Control
7	692993	End Cap, Console (L.H. & R.H.)
8	348689	Screw, End Cap Mounting (4) (6-32 x 3/4)
9	694091	Screw, Mounting (2) #8 Posidrive
10	64093	Switch, Water Level
11	342202	Screw, Tapping (6)
12	660393	Switch, Water Temperature 370145 (Alt.) 370146 (Alt.)
13	693711	Sleeve, Console Lock Screw (2)
14	693151	Spring, Console Lock (2)
15	693710	Screw, Console Lock (2)
16	3388255	Timer, Control (60 Hz.) (Dryer) (Timer Motor Not Serviceable)
17	693175	Strut, Console
18	693169	Switch, Push-To-Start
19	693152	Bumper, Console (5)
20	96435	Screw, Timer Mounting (2)
21	694037	Clip, Console
22	98139	Screw, Dryer Timer Mounting (2) (8-32 x 5/16)
23	694333	Panel, Control
24	696352	Knob & Skirt, Dryer Timer
25	3388562	Button, Push-To-Start
26	696342	Knob & Clip, Water Level
27	696342	Knob & Clip, Water Temperature
28	3388182	Dial, Timer
29	3347726	Knob, Timer
30	688805	Clip
31	692983	Lock, Console (2)
32	694419	Buzzer

DRYER FRONT PANEL AND DOOR PARTS

For Models: LT5000XSW1 and LT5004XSW1
LT5000XSW2 and LT5004XSW2



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

747-C-12

1	692728	Harness, Door Switch (Includes Illus. 1A)
1A	717253	Plug, Terminal (2-Way) (Connects With Main Dryer Harness)
2	347207	Switch, Door
3	295998	Lever, Door Switch
4		Panel, Front
	692619	White
	692620	Almond
	692623	Golden Harvest
	692621	Toast
	692622	Platinum
5	685763	Seal, Door
6	695656	Door, Rear
7		Door, Front
	348205	White
	689314	Almond
	689319	Golden Harvest
	695214	Toast
	695215	Platinum
9	349462	Bearing & Seal
10	685203	Clip, Felt Pad (2)
11	696144	Strike, Panel
12	98129	Screw, Door Switch Mounting (2)
13	343641	Screw, 10-16 x 1/2 (2) (Front Panel To Side Panel)
14	3389441	Catch, Door
15		Handle, Door
	686715	White
	689306	Almond
	689584	Golden Harvest
	695285	Toast
	695286	Platinum
16	692846	Support Protector
17	693739	Fastener, Push (2)
18	339554	Screw, Console Strut Mounting
19	694091	Screw, Door Mount To Hinge & Panel (10)
20	348023	Hinge & Pin, Door (2)
21	693303	Barrier, Harness

DRYER CABINET AND MOTOR PARTS

For Models: LT5000XSW1 and LT5004XSW1
LT5000XSW2 and LT5004XSW2



A 2862

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	660658	Clamp, Motor Mounting (2) 343481 (Alt.) 685441 (Alt.)
2	695074	Motor, Main Drive (60 Hz.)
3	337351	Switch, Motor Start
4	61806	Power Resistor & Shield
5	696541	Bracket, Motor
6	692626	Panel, Rear
7	343641	Screw, 10-16 x 1/2
8	307972	Cover, Terminal Block
9	687128	Screw, 10-16 x 1/2
10		Panel, Side (L.H.)
	692613	White
	692614	Almond
	692617	Golden Harvest
	692615	Toast
	692616	Platinum
11		Plug, Side Panel (2)
	692790	White
	692791	Almond
	692794	Golden Harvest
	692792	Toast
	692793	Platinum
12	687261	Wire, Motor Ground
13	308544	Screw, 10-24 x 1/2 (8) (Mounts Dryer To Dryer Supports)
14	695524	Elbow, Upper
15	237823	Clip, Front Panel (2)
16	98234	Clip, Ground
17	696045	Elbow, Lower
20	345675	Belt, Drive
21	694872	Pulley, Motor (60 Hz.)
22	691366	Idler & Bracket
23	692771	Nut, Idler Bracket To Base
24	696046	Base, Dryer
25	692400	Nut, Push-In
26	692926	Cove, Transition Panel (Black)
27		Panel, Transition
	692933	White
	692934	Almond
	692937	Golden Harvest
	692935	Toast
	692936	Platinum
28	692641	Top, Dryer
29		Panel, Side (R.H.)
	692607	White
	692608	Almond
	692611	Golden Harvest
	692609	Toast
	692610	Platinum
30	693145	Latch, Lid
31		Closure, Control Area
	692781	White
	692782	Almond
	692785	Golden Harvest
	692783	Toast
	692784	Platinum
32	354975	Screw & Washer (3) (Lid Latch Mounting)
33	693304	Screw & Washer (2) (Transition Panel To Closure)
34	64247	Screw, Ground (2) (10-32 x 1/2)

35	9420601	Screw, Tapping (Resistor To Base) (10-16 x 5/16)
36	357021	Capacitor, Motor Start (Automatic Washer)
37	357030	Clamp, Capacitor
38	343641	Screw, Capacitor Mounting (10-16 X 1/2)

DRYER BULKHEAD PARTS

For Models: LT5000XSW1 and LT5004XSW1
LT5000XSW2 and LT5004XSW2



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	343641	Screw, 10-16 x 1/2
2	345396	Clip, Air Duct To Bulkhead
3	696547	Air Duct & Bracket
4	90767	Screw, 8A x 3/8 (Hex Head)
5	660040	Thermostat, Operating (140 oF) (60.0 oC) 342812 (Alt.)
6		Screw, Terminal Block To Bracket (2)
7	690261	Block, Terminal
8	3388703	Washer
9	687128	Screw, 10-16 x 1/2
10	337272	Clip, Heater Box To Bulkhead
11	685457	Heater Box (120/240 Volts)
12	696632	Element, Heater
13	339956	Seal, Air Duct To Bulkhead
14	696426	Wheel, Blower
15	9416643	Screw, 10-16 x 1/2 (3) (Fan Scroll To Bulkhead)
16	696658	Seal, Fan Scroll
17	696418	Fan Scroll
19	696818	Thermostat, Heater Box (225 oF) (107.2 oC)
20	696820	Harness, Thermostat & Heater (Includes Illus. 20A)
20A	692997	Plug, Multi-Terminal (Connects With Main Dryer Harness)
21	339489	Shaft, Drum Roller (R.H.)
22	695943	Drum, Dryer
23	297936	Ring, Bearing
24	685207	Baffle, Drum (3)
25	690372	Screw, Baffle Mounting (6) (11-16 x 7/8)
26	345648	Seal, Drum Rear
27	695931	Bulkhead
28	348399	Lint Screen
29	685273	Cover, Lint Screen Outlet
30	690997	Tri-Ring (4)
31	347364	Shaft, Drum Roller (L.H.)
32	349241	Roller, Support (2)
33	348197	Washer, Support (4)
34	120377	Nut, 3/8-16 (2)
35	342202	Screw, Tapping (4) (Bulkhead To Base)
36	696821	Harness, Main Dryer Wiring (Includes Illus. 36A, 36B & 36C
36A	717252	Receptacle, Terminal (2-Way) (Connects With Door Switch Harness)
36B	692998	Receptacle, Multi-Terminal (Connects With Thermostat & Heater Harness)
36C	717315	Receptacle, Terminal (2-Way) (Connects With Automatic Console Harness)
37	693141	Clip, Wiring Harness (3)
38	694045	Cord, Power (3 Prong) (Use W/Model LT5000XMW1 & Strain Relief Clip 694415)
	694276	Cord, Power (4 Prong) (Use W/Model LT5004XMW1 & Strain Relief 687000)
38A	694415	Clip, Strain Relief (Power Cord) (Use W/3 Prong Power Cord)
38B	687000	Strain Relief, Power Cord (Use W/4 Prong Power Cord)
39	279457	Wire Kit (For Heater Element Wiring Harness Repair)
41	279393	Screw Kit (For Terminal Block)
42	279318	Terminal, Tinned & Brass (3) (Includes Illus. 41)
43	690989	Screw, Ground (2) (10-32 x 1/2)
45	61894	Heater, Thermostat
46	695240	Screw, 8-18 X 1/2 (2)
47	694511	Fuse, Thermal
48	359702	Cap, Screw
49	255563	Clip, Strain Relief

DRYER SUPPORTS AND WASHER CABINET HARNESS PARTS

For Models: LT5000XSW1 and LT5004XSW1
LT5000XSW2 and LT5004XSW2



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	694304	Cover, Channel
2	692647	Support, Dryer (L.H.)
3	343641	Screw, 10-16 x 1/2
4	308544	Screw, 10-24 x 1/2 (8) (Washer Cabinet To Dryer Supports)
5	692646	Support, Dryer (R.H.)
6	3388677	Harness, Upper (Automatic) (Includes Illus. 6A, 6B & 6C
6A	696074	Plug, Terminal (12-Way) (Connects With Automatic Console Harness)
6B	62889	Plug, Terminal (3-Way) (Connects With Automatic Lid Switch Harness)
6C	62505	Block, Disconnect (Connects With Automatic Washer Motor)
7	696633	Clip, Wiring Harness (8)
8	696636	Clip, Pressure Switch Hose And Wiring Harness (3)
10	9412221	Screw, 8-32 x 1/4 (2) (Motor Ground)
11	90016	Clip, Pressure Switch Hose (2)
12	693141	Clip, Harness And Hose

WASHER TOP AND LID PARTS

For Models: LT5000XSW1 and LT5004XSW1
LT5000XSW2 and LT5004XSW2



1	359243	Screw, Lid
2		Lid Handle
	379884	White
	379885	Almond
	379890	Toast
	379891	Platinum
	379888	Golden Harvest
3		Lid
	3348018	White
	3348019	Almond
	3348022	Golden Harvest
	3348021	Toast
	3348020	Platinum
4	384475	Bumper, Lid (2)
5	384458	Hinge, Lid (L.H.)
6	21097	Pad, Lid Hinge (2)
7	18724	Screw, Lid Hinge Mounting (4)
8	343641	Screw, 10-16 X 1/2 (2)
9	692985	Clip, Spring (2) (Top To Cabinet)
10	54690	Plug, Button (2)
11	384460	Spring, Lid (L.H.) (Includes Illus 10)
12		Top
	384693	White
	384694	Almond
	384697	Golden Harvest
	384698	Toast
	384699	Platinum
13	19119	Bumper, Lid Hinge (2)
14	21258	Bearing, Lid Hinge (2)
15	354764	Screw & Washer, Lid Switch Shield (2)
16	357913	Strike, Lid Switch
17	384459	Hinge, Lid (R.H.)
18	274707	Screw, Ground (10-24 X 1/2)
19	357347	Actuator, Lid Switch
20	271166	Nut, Ground Screw (10-24)
21	384461	Spring, Lid (R.H.) (Includes Illus. 10)
22	661517	Switch, Lid 388322 (Alt.) 3347287 (Alt.) 359230 (Alt.)
23	90016	Clip, Harness Routing
24	359231	Shield, Lid Switch
25	697381	Harness, Lid Switch
25A	62888	Receptacle, Terminal (3-Way) (Connects With Harness)

WASHER CABINET PARTS

For Models: LT5000XSW1 and LT5004XSW1
LT5000XSW2 and LT5004XSW2



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	356746	Clip, Condenser (2)
2	343641	Screw, 10-16 X 1/2
3	62863	Screw, Mixing Valve Mounting (2) (10-16 X 3/8)
5	358992	Valve, Water Mixing
6	272846	Clamp, Hose
7	692699	Hose, Water Inlet (Siphon Break To Mixing Valve)
8		Cabinet
	696013	White
	696014	Almond
	696015	Golden Harvest
	696016	Toast
	696017	Platinum
10	696710	Hose, Drain
11	692400	Nut, Push-In (2)
12	660975	Plug, Top To Cabinet 689587 (Alt.) 694010 (Alt.)
13	356739	Connector, Hose
14	272855	Clamp, Hose
15	356471	Cap, Siphon Break
16	356363	Siphon Break
17	272861	Clamp, Hose
18	696394	Hose, Water Inlet (Siphon Break To Tub Ring)
21	272858	Clamp, Hose
22	237823	Clip, Front Panel (2)
23	358652	Link, Leveling
24	359364	Clip, Leveling Mechanism (2)
25	98234	Clip, Ground
26	345670	Lock, Top (2)
27		Panel, Front
	692628	White
	692629	Almond
	692632	Golden Harvest
	692630	Toast
	692631	Platinum
28	367594	Foot, Front (2)
29	358594	Foot, Rear (2)
30	308544	Screw, 10-24 X 1/2 (Washer Cabinet To Dryer Supports)
31	694398	Pad, Extruder (2)
32	3390046	Protector, Edge

BRAKE CLUTCH, GEARCASE, MOTOR AND PUMP PARTS

For Models: LT5000XSW1 and LT5004XSW1
LT5000XSW2 and LT5004XSW2



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	387948	Brake And Drive Tube (Complete) (Refer To Parts Page For Further Breakdown)
2	63292	Washer, Spin Tube Thrust
3	62697	Ring, Spin Tube Support
4	63283	Ring, Retainer
5	64176	Clutch (Complete)
6	388190	Band And Lining (Includes Illus. 7 & 8)
7	64177	Spring, Clutch
8	62646	Cap, Clutch Spring (2)
9	389246	Gearcase (Complete)(Refer To Parts Page For Further Breakdown)
10	62735	Screw, 5/16-24 x 3/16 (3) (Gearcase To Tub Support)
11	62611	Plate, Motor Mount To Gearcase
12	98062	Screw, 5/16-24 x 5/8 (2)
13	285140	Coupling, Motor & Isolating
14	3349644	Motor, Main Drive
15	3349322	Clip
16	63761	Plate, Motor
17	238614	Bumper (2)
18	3348015	Pump, Complete
19	62700	Retainer, Pump
20	62850	Switch, Main Drive Motor
21	62691	Grommet, Motor (4)
22	3349637	Retainer, Motor (2)
23	3350013	Foam
24	357640	Screw (2) #10-16 x 5/8

MACHINE BASE PARTS

For Models: LT5000XSW1 and LT5004XSW1
LT5000XSW2 and LT5004XSW2



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	285203	Centerpost Bearing Kit (Incls. Illus. 10, 11, & 12)
3	64137	Shield, Tub
4	62738	Spring, Counterweight
5	63731	Suspension Assembly (3)
6	63755	Base
10	356934	Seal, Centerpost (2)
11	3347047	Bearing, Centerpost (2)
12	357409	Seal, Centerpost (3)
13	63134	Ring, Sound Deadening
14	98610	Screw, 10-16 X 5/8 (2)
15	63636	Bracket, Counterweight Spring
16	63207	Retainer, Spring
17	63637	Shield, Tub
18	3347149	Nut, 1/2 - 13 (1)
19	63740	Tub Support and Drum
21	359262	Screw, 10-32 X 1/2 (Grounding)
22	90767	Screw, 8A X 3/8 (4)
23	386011	Screw & Washer (Base To Cabinet)
24	696044	Block, Restraint (2)

TUB AND BASKET PARTS

For Models: LT5000XSW1 and LT5004XSW1
LT5000XSW2 and LT5004XSW2



7613

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

242-0-9

1	63911	Cap, Agitator
2	358237	Screw & Washer (5/16-24 x 1)
3	63840	Filter, Agitator
4	3349098	Agitator
5	64175	Tub Ring & Gasket (Includes Illus. 7, 14 & 15)
6	21366	Nut, Spanner
7	64000	Gasket, Tub Ring
8	64081	Basket
9	63782	Tub
10	389140	Block, Basket Drive
11	696238	Hose, Pressure Switch
12	371502	Clamp, Hose
13	386929	Hose, Tub To Pump
14	352155	Clip, Retaining (2)
15	356398	Tube, Drain Off
16	98005	Screw & Washer (Tub Mounting) (4)
17	383727	Gasket, Centerpost

WASHER WATER SYSTEM PARTS

For Models: LT5000XSW1 and LT5004XSW1
LT5000XSW2 and LT5004XSW2



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	285321	Sleeve Kit, Plastic Drain Hose (Contains 2 Sleeves)
2	65349	Clamp, Hose (2)
3	16272	Connector, Straight
4	285320	Siphon Break Kit (Not Included)
5	384688	Hose, Corrugated Plastic Drain (5-1/2 Ft.)
	384498	Hose, Corrugated Plastic Drain (10 Ft.) (Not Included)
6	357247	Retainer, Drain Hose
7	371504	Clamp, Hose
8	384496	Coupling, Hose
9	370445	Clamp, Hose
10	356739	Connector, Hose
11	660028	Hose, Inlet (2) 81339 (Alt.) 366108 (Alt.)

GEARCASE PARTS

For Models: LT5000XSW1 and LT5004XSW1
LT5000XSW2 and LT5004XSW2



GC 212 A

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	389246	Gearcase (Complete)
2	62685	Cover, Gearcase
3	3347188	Seal, Gearcase Cover
4	285195	Sealer, Gasket (.20 Fl. oz.) (6 Ml.)
5	63320	Pinion, Spin (Includes Illus. 25)
6	356427	Seal, Spin Pinion
7	389387	Shaft, Agitator (Complete)
8	90369	Ring, Retaining (2)
9	62677	Retainer, Spring
10	62676	Spring, Agitator
11	63273	Gear, Agitator
12	62619	Washer, Agitator Gear
13	62580	Follower, Cam
14	62581	Cam, Agitator
15	389231	Shaft, Agitator
16	62618	Washer, Cam Thrust
17	16018	Bearing, Thrust
18	85529	Ball, Bearing
19	389229	Bottom and Pinion, Gearcase
20	62528	Gear, Main Drive
21	285352	Seal, Thrust Plug
22	90864	Screw, Gearcase Cover Mounting (8)
23	95082	Ring, Retaining
24	285292	Washer Kit, Thrust
25	62570	Gear, Spin
26	388253	Neutral, Assembly
27	62534	Rack, Connecting
28	62621	Actuator, Shift
29	388815	Washer, Intermediate

BRAKE AND DRIVE TUBE PARTS

For Models: LT5000XSW1 and LT5004XSW1
LT5000XSW2 and LT5004XSW2



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	387948	Brake And Drive Tube (Complete)
2	62658	Ring, Thrust
3	91939	Seal, Oil
4	356427	Seal, Drive Tube
5	356937	Spacer, Drive Tube
6	64027	Tube, Basket Drive (Includes Illus. 3, 4, 5 & 9)
7	64035	Ring, Retaining
8	64232	Brake Shoe
9	62703	"T" Bearing, Spin Tube
10	62648	Cap, Brake Spring (2)
11	63748	Spring, Brake
12	62909	Sleeve, Brake Spring
13	661516	Cam, Brake Release 63023 (Alt.) 3348288 (Alt.)
14	63022	Sleeve, Cam
15	64194	Driver, Brake Cam
16	90368	Ring, Retaining

SALES ACCESSORY PARTS
(OPTIONAL PARTS NOT INCLUDED)

For Models: LT5000XSW1 and LT5004XSW1
LT5000XSW2 and LT5004XSW2

LCK 4500



LCK 4600



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	694609	Exhaust Deflector Kit (Complete)
2	687128	Screw, Mounting (2) (10-16 X 1/2) (Hex Washer Head)
1	694646	Side Exhaust Extension Kit (Complete)
2	687128	Screw, 10-16 X 1/2(3) (Hex Washer Head)

MISCELLANEOUS PARTS

For Models: LT5000XSW1 and LT5004XSW1
LT5000XSW2 and LT5004XSW2



1	3390548	Miscelleous Parts Bag
2	16123	Washer, Inlet Hose
3	370445	Clamp, Hose
4	367594	Foot, Front (2)
5	358594	Foot, Rear (2)
6	3347868	Tie, Cable
7	357247	Retainer, Wire

LITERATURE PARTS

LIT693030	Guide, Laundry
LIT3389581	Instructions, Installation (For Models: LT5000XSW1 and LT5000XSW2)
LIT3389582	Instructions, Installation (For Models LT5004XSW1 and LT5004XSW2)
LIT3388935	Guide, Use And Care
LIT693019	Instructions, Operating
LIT386215	Label, Energy Guide (For Models LT5000XSW1 and LT5000XSW2)
LIT386216	Label, Energy Guide (For Models LT5004XSW1 and LT5004XSW2)
LIT3388366	Label, Wiring Diagram (For Models LT5000XSW1 and LT5000XSW2)
LIT3388367	Label, Wiring Diagram For Models LT5004XSW1 and LT5004XSW2)
LIT693126	List, Repair Parts

OPTIONAL PARTS NOT INCLUDED

PAINT, TOUCH-UP (1/2 oz.)

72017	White
72107	Almond
72112	Toast
72113	Platinum
72110	Golden Harvest

PAINT, PRESSURIZED SPRAY (13 oz.)

350941	Leveler (Thinner)
350938	Primer, Gray
350930	White
350956	Almond
285365	Toast
285366	Platinum
261890	Golden Harvest

PAINT, BULK (1 qt.)

799344	White (Uncut)
978883	Almond (Uncut)
285367	Toast (Uncut)
285368	Platinum (Uncut)
261891	Golden Harvest (Uncut)

OIL

350572	Oil, Gearcase (16 Oz.)

LUBRICANT

285208	Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)

SEALER

285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)